





Connection on k.p.



- b1 Main switch
b2 Door switch
b2.1 Light switch
b3 Timer switch
b4 Drying selector
b5 Temp selector 550C
b5.1 Temp selector 400C
b1 Overfilling protector
f1 Thermostat 650C
f2 Thermostat 550C
f2.1 Thermostat 400C
f3 Overheating protector
f3.1 Overheating protector

- f4 Safety pressostat
f5 Level pressostat
h1 Lamp
h7 Lamp dishroom
k1 Net terminal
k2 Reacting relay
m1 Timer motor
m2 Main pump
m3 Drain pump
R1 Element 1800 W
R2 Element 1000 W
R3 Element 2800 W

- s2/4 Dispensers
s3 Regeneration valve
Fu Fuse
k1 Start capacitor
k2 PRL Capacitor
Tr Transformer
--- Internal connection on timer
--- Connection with wire
*) Term on timer
*) Contact between A3 and C3 softener system only
**) Not in all models

